




**COMMERCIAL GAS SERVICE PARTS LIST**

State Water Heater Parts Fulfillment  
125 Southeast Parkway • Franklin, TN 37068  
www.statewaterheaters.com • 1-800-821-2017

**MODELS:  
SUF 60-120 through SUF 100-250  
SERIES 100/101**


**DISPLAY CONTROL ASSEMBLY**  
See Page 2




SUF 60-120 through SUF 100-250  
See Page 2




**INNER COVER CONTROL ASSEMBLY**  
See Page 3




**BLOWER/BURNER ASSEMBLY**  
See Page 4 & 5




**GAS VALVE**  
See Page 6



**ELECTRONIC ANODE**  
See Page 8



**EXHAUST ELBOW ASSEMBLY - VENT KIT ASSEMBLY**  
See Page 7





## CLEANOUT ASSEMBLY/TEMPERATURE & PRESSURE VALVE

SUF 60 120/A      SUF 100 150/A      SUF 100 199/A      SUF 100 250/A

Item	Description	100/101	100/101	100/101	100/101
1	Cleanout Gasket.....	9004099015.....	9004099015.....	9004099015.....	9004099015
2	Cleanout Plate.....	9004098005.....	9004098005.....	9004098005.....	9004098005
3	T & P Valve.....	9005899205.....	9005899205.....	9005899205.....	9005903205
4	Lower Probe.....	9006242015.....	9006242015.....	9006242015.....	9006242015
5	Thread Forming Screws.....	9004100215.....	9004100215.....	9004100215.....	9004100215


Standard hardware items may be purchased locally.



## DISPLAY CONTROL ASSEMBLY

SUF 60 120/A      SUF 100 150/A      SUF 100 199/A      SUF 100 250/A

Item	Description	100/101	100/101	100/101	100/101
1	SUF Display Overlay.....	9006241005.....	9006241005.....	9006241005.....	9006241005
2	On/Off Switch.....	192699-000.....	192699-000.....	192699-000.....	192699-000
3	Switch Wire Connection.....	197758-000.....	197758-000.....	197758-000.....	197758-000
4	Display Panel.....				
5	User Interface Module - UIM.....	9006240005.....	9006240005.....	9006240005.....	9006240005
6	Splatter Shield.....	197763-000.....	197763-000.....	197763-000.....	197763-000




## INNER COVER CONTROL ASSEMBLY - 60 120/A & 100 150/A

Item	Description	SUF 60 120/A		SUF 100 150/A	
		100	101	100	101
1	Controller.....	9006300005.....	9006304005.....	9006301005.....	9006305005
2	Switch-blower prover.....	9006280015.....	9006280015.....	9006280015.....	9006280015
3	Switch-blocked inlet.....	9006288015.....	9006281015.....	9006288015.....	9006281015
4	Switch-blocked outlet.....	9006287015.....	9006287015.....	9006289015.....	9006287015
5	Upper Probe.....	9004238215.....	9004238215.....	9004238215.....	9004238215

## INNER COVER CONTROL ASSEMBLY - 100 199/A & 100 250/A

Item	Description	SUF 100 199/A		SUF 100 250/A	
		100	101	100	101
1	Controller.....	9006302005.....	9006306005.....	9006303005.....	9006307005
2	Switch-blower prover.....	9006280015.....	9006280015.....	9006280015.....	9006280015
3	Switch-blocked inlet.....	9006288015.....	9006281015.....	9006281015.....	9006281015
4	Switch-blocked outlet.....	9006289015.....	9006282015.....	9006282015.....	9006282015
5	Upper Probe.....	9004238215.....	9004238215.....	9004238215.....	9004238215

Standard hardware items may be purchased locally.




## BURNER/BLOWER ASSEMBLY - 60 120/A & 100 150/A

SUF 60 120/A


SUF 100 150/A

Item	Description	SUF 60 120/A		SUF 100 150/A	
		100	101	100	101
1	Blower Assembly.....	9006272005.....	9006272005.....	9006273005.....	9006273005
2	Burner.....	9006275005.....	9006276005.....	9006277005.....	9006278005
3	Burner Flange.....	197932-000.....	197932-000.....	197932-000.....	197932-000
4	Burner Gasket.....	9006909005.....	9006909005.....	9006909005.....	9006909005
5	Condensate Tee.....	197624-001.....	197624-001.....	197624-001.....	197624-001
6	Coupling-Power Vent.....	9006107205.....	9006107205.....	9006107205.....	9006107205
7	Flame Sensor.....	9006106205.....	9006106205.....	9006106205.....	9006106205
8	Flange Gasket.....	9007138005.....	9007138005.....	9007138005.....	9007138005
9	Igniter.....	9006101205.....	9006101205.....	9006101205.....	9006101205
10	Observation Window.....	9006102215.....	9006102215.....	9006102215.....	9006102215
11	Mesh Wire Screen.....	9006027015.....	9006027015.....	9006027015.....	9006027015
12	Stud 5-16-18 x 1 3/4".....	196881-000.....	196881-000.....	196881-000.....	196881-000
13	Truss Hd Machine Screw 1/4-20 x1.00".....	194816-000.....	194816-000.....	194816-000.....	194816-000
14	Viewport Gasket.....	9006103215.....	9006103215.....	9006103215.....	9006103215



## BURNER/BLOWER ASSEMBLY - 100 199/A & 100 250/A


Item	Description	SUF 100 199/A & 100 250/A	SUF 100 199/A & 100 250/A
1	Blower Assembly.....	9006274005.....	9006274005
2	Burner.....	9006279005.....	9008702005
3	Burner - Adapter.....	197607-000.....	197607-000
4	Burner - Gasket A.....	9007139005.....	9007139005
5	Burner Flange.....	197933-000.....	197933-000
6	Burner - Gasket B.....	9006909005.....	9008703015
7	Condensate Tee.....	197624-000.....	197624-000
8	Flame Sensor.....	9006106205.....	9006106205
9	Flange - Gasket.....	9007138005.....	9007138005
10	Gas Valve - Venturi Assembly.....	9006285005.....	9006286005
11	Hose Barb.....	181863-000.....	181863-000
12	Igniter.....	9006101205.....	9006101205
13	Intake Connector.....	197604-000.....	197604-000
14	Switch-Low Gas Pressure.....	9006256015.....	9006255015
15	Observation Window.....	9006102215.....	9006102215
16	Stud 5/16-18 x 1 3/4".....	196881-000.....	196881-000
17	Truss Hd Machine Screw 1/4-20 x 1.00.....	194816-000.....	194816-000
18	Venturi Gasket.....	197789-000.....	197789-000
19	Venturi Mounting Screw.....	197790-000.....	197790-000
20	Viewport Gasket.....	9006103215.....	9006103215
21	Mesh Wire Screen.....	9006027015.....	9006027015



## GAS VALVE ASSEMBLY - 60 120/A

Item	Description	SUF 60 120/A	SUF 60 120/A
		100	101


1	Gas Valve .....	9004535205.....	9004536205
2	Orifice .....	9006259015.....	9006257015
3	Orifice Holder .....	9006094215.....	9006094215
4	Switch - Low Gas Pressure .....	9006256015.....	9006255015



## GAS VALVE ASSEMBLY - 100 150/A

Item	Description	SUF 100 150/A	SUF 100 150/A
		100	101

1	Gas Valve .....	9006283005.....	9006284005
2	Orifice .....	9006260015.....	9006258015
3	Orifice Holder .....	9006094215.....	9006094215
4	Switch - Low Gas Pressure .....	9006256015.....	9006255015





## EXHAUST CONNECTOR ASSEMBLY - 60 120/A - 100 250/A

SUF 60 120/A - 100 250/A

100/101

Item	Description	100/101
1	Exhaust Connector.....	9006157205
2	Exhaust Elbow Assembly.....	9007245005






## VENT KIT ASSEMBLY - 60 120/A - 100 250/A

SUF 60 120/A - 100 250/A


100/101

Item	Description	100/101
1	Exhaust Screen.....	9006027015
2	Intake - Screen Collar Assembly.....	182162-000
3	PVC 45 Degree Elbow.....	181901-000
4	Silicone.....	9004365105
5	Wall Plate.....	9004364105



**ELECTRIC ANODE ASSEMBLY - 60 120/A - 100 250/A**

Item	Description	SUF 60 120/A	SUF 100 150/A, 199/A, 250/A
		100/101	100/101
1	Electric Anode .....	-----	9006246005
2	Electric Anode .....	9006559005.....	9006247005



**OPTIONAL VENT KIT ASSEMBLY FOR 4" VENTING (ALL MODELS) 9006311005**

Item	Description	SUF 60 120/A - 100 250/A
		100/101
1	Silicone .....	-----
2	Wall Plate .....	-----
3	Vent Terminal Assembly 4" .....	-----

