



NOTES:

1. Preferred piping diagram.

2. The temperature and pressure relief valve setting shall not exceed pressure rating of any component in the system.

3. Service valves are shown for servicing unit. However, local codes shall govern their usage.

4. The tank temperature control should be wired to and control the pump between the water heater(s) and the storage tank(s).

5. The water heater's operating thermostat should be set 5°F higher than the tank temperature control.

June 2011 | Printed in U.S.A. | © State Water Heaters For Technical Information and Automated Fax Service, call 800-365-0024 or visit www.statewaterheaters.com. State Water Heaters reserves the right to make product changes or improvements without prior notice.